
LI = Load Index (kantavuusindeksi)

LI	KG	LI	KG	LI	KG
0	45	45	165	90	600
1	46.2	46	170	91	615
2	47.5	47	175	92	630
3	48.7	48	180	93	650
4	50	49	185	94	670
5	51.5	50	190	95	690
6	53	51	95	96	710
7	54.5	52	200	97	730
8	56	53	206	98	750
9	58	54	212	99	775
10	60	55	218	100	800
11	61.5	56	224	101	825
12	63	57	230	102	850
13	65	58	236	103	875
14	67	59	243	104	900
15	69	60	250	105	925
16	71	61	257	106	950
17	73	62	265	107	975
18	75	63	272	108	1000
19	77.5	64	280	109	1030
20	80	65	290	110	1060
21	82.5	66	300	111	1090
22	85	67	307	112	1120
23	87.5	68	315	113	1150
24	90	69	325	114	1180
25	92.5	70	335	115	1215
26	95	71	345	116	1250
27	97.5	72	355	117	1285
28	100	73	365	118	1320
29	103	74	375	119	1360
30	106	75	387	120	1400
31	109	76	400	121	1450
32	112	77	412	122	1500
33	115	78	425	123	1550
34	118	79	437	124	1600
35	121	80	450	125	1650
36	125	81	462	126	1700
37	128	82	475	127	1750
38	132	83	487	128	1800
39	136	84	500	129	1850
40	140	85	515	130	1900
41	145	86	530	131	1950
42	150	87	545	132	2000
43	155	88	560	133	2060
44	160	89	580	134	2120